



2000W CERAMIC FAN HEATER

*Please refer to the warranty section for terms of your extended guarantee



READING AND STORING THE USER MANUAL



Before using this product, please read through this manual carefully paying particular attention to the safety instructions. Failure to do so may result in personal injury or damage to the product.

Carefully save this instruction manual for future reference. Ensure the user manual is included when passing the product on to any third parties.

IMPORTANT SAFETY INSTRUCTIONS FOR PROPER USE

When using electrical appliances, basic safety precautions should always be followed.

Only use the product as described in this user manual. Any other use is considered improper and may result in damage to property or persons. The manufacturer or vendor cannot be held liable for damages or injury incurred through improper or incorrect use.

- **Read and familiarise yourself with all operating instructions before using this PTC Heater.**
- Before plugging your unit into the mains, visually check that the unit is intact and has not suffered any transit damage.

⚠️ WARNING! In order to avoid overheating, **DO NOT COVER** the heater.

⚠️ WARNING! To reduce the risk of fire, keep textiles, curtains, or any other flammable material a minimum distance of 1m from the air outlet.

- **DO NOT** locate the appliance immediately below an electrical socket outlet.
- **DO NOT** use this heater with a programmer, timer, separate remote-control system or any other device that switches the heater on automatically, since a fire risk exists if the heater is covered or positioned incorrectly.
- **DO NOT** use this heater with an extension cable.
- Check that the voltage indicated on the data plate corresponds with that of the local network before connecting the appliance to the mains power supply.

- Close supervision is required when using this appliance near children.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Children of less than 3 years should be kept away unless continuously supervised.
- Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.

 WARNING! Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.

- **DO NOT** use this heater in the immediate surroundings of a bath, a shower or a swimming pool.
- **DO NOT** use this heater in small rooms when they are occupied by persons not capable of leaving the room on their own, unless constant supervision is provided.
- **DO NOT** immerse the appliance or its cord in water or any other liquids.
- **DO NOT** leave the appliance unattended during use.
- **DO NOT** leave the appliance unattended whilst connected to the mains supply.

- Always use this appliance on a solid, level, heat resistant surface.
- **DO NOT** use this appliance outdoors.
- It is imperative to unplug the power cord after the appliance has been used, before it is cleaned and whilst being repaired.
- Repairs to electrical appliances should only be performed by a qualified electrician. Improper repairs may place user at serious risk.
- **DO NOT** operate this appliance with a damaged plug or cord, after a malfunction or after being dropped or damaged in any way.
- Regular, periodic checks should be carried out on the mains cable to ensure no damage is evident. Should there be any signs of damage the appliance should not be used.
- If the power cable is damaged, it should only be replaced by the manufacturer or a suitable qualified after-sales-service in order to avoid a hazard
- **DO NOT** allow the mains cable to hang over sharp edges or come in contact with hot surfaces.
- **DO NOT** run the mains cable under carpets, rugs, etc.
- Allow the unit to cool before storage.
- Before cleaning, disconnect the appliance from the mains supply and allow to cool.
- Never place the appliance near to flammable material or high pressure containers. E.g. Paper, wood, petrol, solvents, spray canisters.
- This appliance is intended for household use only and should not be used for industrial purposes.
- **DO NOT** use any accessories or attachments with this appliance other than those supplied or recommended by supplier.
- **DO NOT** use this appliance for anything other than its intended use.

- **DO NOT** push objects into any openings as damage to the appliance and/or electric shock may occur.
- The appliance should not be installed in areas which have a fire-risk, such as garages, stables or wooden sheds; this is applicable also for rooms in which highly inflammable gasses or dust can develop. Danger of fire!!
- Unplug after each use. Grasp the plug, not the cord.

CAUTION 


Keep Hearth Rugs and other soft furnishings away from the front of the heater. They could obstruct the free flow of air from the fan and damage both soft furnishings and heater.

The heater must stand on a solid, level non-flammable surface such as stone, slate, ceramic or concrete.

DO NOT Stand the heater on a carpet, rug or other soft floor covering.

DO NOT COVER THE HEATER

This appliance has been ERP classified as a portable space heater and should only be used for supplementary, secondary or temporary heating. It should not be considered for primary permanent heating in a room or dwelling.

 During the first few minutes of initial use, you may notice a slight odour and a little smoke. This is normal and will quickly disappear, It is the coating applied to the heating elements to prevent any corrosion during transit.

Explanation of Symbols


The following warning symbols or words are used in this instruction manual:




Products labelled with UK Conformity Assessment identifies products conforming to UK statutory requirements.



Products labelled with this symbol conform to applicable provisions of the European Economic Area.



This Class 2 symbol indicates that the product is electrically double insulated and does not require an earth connection.



You should now recycle your waste electrical goods and in doing so help the environment. This symbol means waste electrical products at the end of their useful life should not be disposed of with normal household waste and not sent to landfill. Please ensure it is taken to a suitable facility for disposal. Check with your Local Authority or retailer for recycling advice or visit www.recycle-more.co.uk or www.weeeireland.ie enter your postcode to find out your nearest recycling site.



This symbol provides useful additional information on the use of this product.




This symbol indicates that the supply uses an alternating current mains supply.



This designates a hazard with moderate risk, which may result in severe injury if not adhered to.

Description of Parts



1. Thermostat Control
2. Power Indicator
3. Heating Element
4. Oscillating Base
5. On/Off/Fan/Heat Dial
6. Air Inlet (Rear)
7. Tip over switch (Base)

Before First Use of Your PTC Heater

Remove all packing materials and discard responsibly.

Operating Instructions

- Place the heater on a solid, level, heat resistant surface.
- Ensure that the **Thermostat Control** (1) is fully rotated anti-clockwise to the 'Off' position.
- Insert the Mains Plug into a suitable socket outlet.
- For the low heat setting, rotate the **On/Off/Fan/Heat Dial** (5) to the low heat position (I).
- For the high heat setting rotate the **On/Off/Fan/Heat Dial** (5) to the high heat position (II).
- Once you have selected low or high, rotate the **Thermostat Control** (1) clockwise to increase the room temperature and anticlockwise to decrease the room temperature as desired. The Indicator (2) will illuminate on and off to indicate that the set temperature is being maintained, this quite normal.
- Return the **On/Off/Fan/heat Dial** (5) to the (O) position to switch off the heater.

Setting the Correct Temperature

- Set the heater to the desired heat setting as above.
- Rotate the **Thermostat Control (1)** to the maximum position and allow the room to warm up. Once the desired room temperature has been reached turn the **Thermostat Control (1)** anticlockwise until the heater just clicks off then turn it back up clockwise very slightly. The **Thermostat Control (1)** will now maintain the room temperature, if necessary, further increasing or decreasing the **Thermostat Control (1)** may be required to 'fine tune' the ideal room temperature.
- Return the **On/Off/Fan/Heat Dial (5)** to the (0) position to switch off the heater.

Fan Only Mode

- Rotate the **On/Off/Fan/Heat Dial (5)** to the fan only position (🌀) to enable the fan to operate without producing heat. The **Thermostat Control (1)** will need to be rotated to the fully clockwise position for the fan to operate.

Oscillating Mode

- Oscillating mode can only be used with the heat turned on.
- For the low heat setting, rotate the **On/Off/Fan/Heat Dial (5)** to the low heat position (↓).
- For the high heat setting rotate the **On/Off/Fan/Heat Dial (5)** to the high heat position (↓↓).

Care and Use of Your PTC Heater

Always disconnect the heater from the mains power supply and allow to cool down before cleaning.

Clean outside of the heater with a clean damp cloth. Never clean with harsh or abrasive cleaners.

DO NOT submerge any part of the heater in water or any other liquids.

DO NOT wrap the Mains Cable around the appliance.

Safety Tip –Over

⚠️WARNING! This appliance is fitted with a built in safety tip-over switch, if the appliance is tilted by 30° or more the cut-out is activated and the unit will stop working. Place the heater back in the upright position and the unit will begin to operate normally.

Safety Cut – Out

⚠️WARNING! This appliance is fitted with a built in safety cut-out, if the cut-out is activated the unit stops working, unplug the heater from the mains and check that the air intake area is not blocked or covered. Leave for an hour to cool and reset before plugging back into the mains.

Technical Specification

Rated Voltage	220-240V~ 50Hz
Rated Power	2000W
Model Number	HEA1975
Protection Class	II

Customer Support

Should you require any product information, replacement parts or accessories, please contact our customer care team on 0161 831 7879 (8.30am-4.30pm Monday to Thursday, 8.00am-4.00pm Friday) and select option 3 or by contacting us via email: help@daewooelectricals.com.

- Replacement parts and accessories are guaranteed for 1 year from the date of purchase.
- It is important to note that your warranty becomes invalid should non Daewoo parts or accessories be used with this appliance.

ErP Data

Model	HEA1975					
Item	Symbol	Value	Unit		Item	Unit
Heat output					Type of heat input, for electric storage local space heaters only (select one)	
Nominal heat output	P_{nom}	2.0	KW		single stage heat output and no room temperature control	No
Minimum heat output (indicative)	P_{min}	1.50	KW		two or more manual stages, no room temperature control	No
Maximum continuous heat output	$P_{max,c}$	1.5	KW		with mechanic thermostat room temperature control	Yes
Power consumption						
At nominal heat output	e_{lmax}	0.0	KW		with electronic room temperature control	No
At minimum heat output	e_{lmin}	0.0	KW		electronic room temperature control plus day timer	No
In standby mode	e_{lSB}	0.0	KW		electronic room temperature control plus week timer	No
In Network standby	P_{nsm}	0.0	KW		Other control options (multiple selections possible)	
Standby mode with display information or status					room temperature control, with presence detection	No
Seasonal Space Heating energy efficiency in active mode	$N_{s,on}$	85	%		room temperature control, with open window detection	No
					distance control option	No
					adaptive start control	No
					working time limitation	No
					black bulb sensor	No
					self-learning functionality	No
					control accuracy	No

Non-Rewireable Mains Plug

If your appliance is supplied with a non-rewireable plug fitted to the mains lead and should the fuse needed replacing, you must use an ASTA approved one (conforming to BS 1362 of the same rating). Never use a plug with the fuse cover missing. If in doubt, consult a qualified electrician.

If you need to remove the plug -**DISCONNECT FROM THE MAINS**- and then cut it off the mains lead and immediately dispose of it safely. Never attempt to reuse the plug or insert it into a socket outlet as there is a danger of electric shock.

Recycling Information


Disposal of the Packaging

Dispose of paper and cardboard in appropriate paper re-cycling facilities.

Dispose of recyclable plastics in appropriate plastic re-cycling facilities.

Dispose of non-recyclable plastics in the appropriate plastics collection service.

Disposal of the Product



You should now recycle your waste electrical goods and in doing so help the environment. This symbol means waste electrical products at the end of their useful life should not be disposed of with normal household waste and not sent to landfill. Please ensure it is taken to a suitable facility for disposal. Check with your Local Authority or retailer for recycling advice or visit www.recycle-more.co.uk or www.weeeireland.ie to find your nearest recycling point.





DAEWOO®

WARRANTY

Thank you for purchasing your Daewoo product.

As part of our commitment to quality, we are offering you an extra 2 years warranty in addition to your 1 year guarantee

Your Daewoo product is guaranteed for 1 year from the date of original purchase, with proof of purchase or receipt. If any defect should occur due to faulty workmanship or material, your faulty product should be returned to the place of purchase, replacement or refund is at the discretion of the retailer.

The guarantee is subject to the following provisions:

- The product must be correctly installed and operated in accordance with the requirements contained in the instruction manual.
- The product must be used solely for domestic purposes.
- It does not cover general wear and tear, damage, misuse or any consumable parts.
- The guarantee will be rendered invalid if the product is re-sold or has been damaged through inexpert repair.
- The guarantee is only valid within the UK and Eire.

Your standard 1 year guarantee will only be extended to the maximum available for your individual product upon registration. (Note: products must be registered individually and covers the main body and housing). If you do not register your product within 28 days of the original purchase date, your product will only be guaranteed for 1 year.

To validate your extended 2 year warranty please register your purchase online within 28 days of the original purchase date by registering at:*

<https://help.daewooelectricals.com>

or

[Contact Us \(daewooelectricals.com\)](https://www.daewooelectricals.com)

*Your extended warranty is only valid with proof of purchase receipt and subject to the conditions outlined above.

Daewoo is a registered trademark.
Produced and imported under licence by
Eurosonic Group Limited
Brightgate House
1 Brightgate Way
Manchester M32 0TB UK
EU Rep: EuroSonic Magppie (ESM) Ltd. Ireland D05 X006
www.esgltd.com